

IMPORTANT: Due to constant improvements in the design and quality of our vehicles, changes to the vehicle configuration can occur during mass-production, which can affect the Owner's Manual information after the supply for production has already been printed.

This addendum is required to correct your Owner's Manual information. Please reference the following for the correction of:

- **2018 ZFORCE Series Owner's Manual – Page 93**
 - **Dashboard Gauge Updated** - An engine hour meter and brightness control were added to the dashboard gauge. The update required a change to the 'SEL' and 'ADJ' button sequencing to access the various functions.
- **Applies To:**
 - **2018 ZFORCE 800/1000 built after 1/10/2018**
 - **2018 ZFORCE 500 built after 5/1/2018**
- **2018 UFORCE Series Owner's Manual – Page 77**
 - **Dashboard Gauge Updated** - An engine hour meter and brightness control were added to the dashboard gauge. The update required a change to the 'SEL' and 'ADJ' button sequencing to access the various functions.
- **Applies To:**
 - **2018 UFORCE 800 built after 5/8/2018**
 - **2018 UFORCE 500 built after 2/6/2018**

CFMOTO-USA apologizes for the error. Store this addendum with your vehicle's paperwork.

2018 UFORCE Owner's Manual - PAGE 77:

CONTROLS AND FEATURES			
Navigating Dashboard Settings / Adjustments			
Item	Displays	SEL / ADJ Button	Result
Mode Toggle	Odometer / Trip Distance / Engine RPM / Engine Hours / Battery Voltage/ Brightness	Short Press SEL Button	ODO→TRIP→RPM→H →V→Brightness
Metric / Standard Toggle	Speed/Distance	Long Press SEL Button and toggle through clock function / Short Press ADJ Button	Metric ↔ Standard Values
Trip Distance Reset	Trip Distance	Long Press SEL Button in Odometer mode	Distance reset to zero
Clock – Hours / Minutes Adjust	Time	Long Press SEL Button Short Press ADJ Button Short Press SEL, then Short Press ADJ in Clock mode	Enter Clock Mode Incremental 1-12 Incremental 00-59
Display Brightness	Brightness Level	Short Press ADJ Button in Brightness Mode	Toggles levels of brightness

The diagram shows a motorcycle dashboard with various gauges and a digital display. Two red arrows point to circular buttons on the left and right sides of the dashboard, labeled 'SEL' Button and 'ADJ' Button respectively.

77

CONTROLS AND FEATURES

Navigating Dashboard Settings / Adjustments

Item	Displays	SEL / ADJ Button	Result
Mode Toggle	Odometer / Trip Distance / Engine RPM / Engine Hours / Battery Voltage/ Brightness	Short Press SEL Button	ODO→TRIP→RPM→H →V→Brightness
Metric / Standard Toggle	Speed/Distance	Long Press SEL Button and toggle through clock function / Short Press ADJ Button	Metric ↔ Standard Values
Trip Distance Reset	Trip Distance	Long Press SEL Button in Odometer mode	Distance reset to zero
Clock – Hours / Minutes Adjust	Time	Long Press SEL Button Short Press ADJ Button Short Press SEL, then Short Press ADJ in Clock mode	Enter Clock Mode Incremental 1-12 Incremental 00-59
Display Brightness	Brightness Level	Short Press ADJ Button in Brightness Mode	Toggles levels of brightness

