

**IMPORTANT:** Due to constant improvement in the design and quality of our vehicles, changes to a vehicle configuration can occur which affect the Owner's Manual information after the supply for production has already been printed.

A change to the front drive shaft during production required additional maintenance information in the form of an addendum to the 2020 UFORCE 1000 Owner's Manual for vehicles with production build dates between *September 5<sup>th</sup>, 2019 and November 19<sup>th</sup>, 2019*.

The VIN plate containing build date information is on the right frame tube and can be viewed by tilting the cargo box.


Please reference the following for front drive shaft maintenance information if your UFORCE1000 UTV has a build date between *September 5<sup>th</sup>, 2019 and November 19<sup>th</sup>, 2019*:

## **Front Drive Shaft Universal Joint Lubrication (Applies to vehicle build dates September 5<sup>th</sup> to November 19<sup>th</sup> 2019)**

Inspect and lubricate according to the maintenance schedule in the owner's manual. If the vehicle is operated in severe conditions, apply grease at the grease nipples more frequently.

To lubricate the universal joints of the front drive shaft:

- Front – Remove the front skid plate to gain access to the drive shaft universal joint nipple at the gear case.
- Rear – Remove the passenger seat bottom and tool box to gain access to the drive shaft universal joint nipple at the engine.
- Apply grease to the front and rear grease nipples (1) until grease begins to flow from the joint.



Disregard this addendum if your UFORCE1000 UTV was built before September 5<sup>th</sup>, 2019, or after Nov 19<sup>th</sup>, 2019.

CFMOTO apologizes for the error.